


### Spare parts list for strapping seal machine

Spare parts name	Qu'ty	USD
1 Double groove pulley	1	
2. Large wheel pulley	1	80
3 Power switch	1	
4. Eccentric	1	107
5. Needle bearing	1	19
6. Cutter mold	1	143
7. Movement	1	13
8. Feeding limit	1	15
9. Back button	1	3.6
10. Small shovel	1	15
11. Top core key	1	13
12. Scissors mouth	1	107
13. Punching bearing and eccentric sleeve for embossing device	1	54
14. embossing punch pin	1	32


15. the embossing mold device upper	1	71
16. The embossing mold device lower	1	71
17. Feeding pairing rollers	1	54
18. Stripper triangle adjustment	1	32
19 The stripper rod	1	
20. Feeding length adjustment screw	1	2
21. Single clutch bearing	1	107
(factory price)		

Spare parts list for the steel strapping seal machine  
全自动钢带冲字打扣机使用说明书

正图 Front view



背图 Back view



- |                                |          |                    |                     |
|--------------------------------|----------|--------------------|---------------------|
| 1、双槽可调加快皮带轮转速。电机功率 1.1 千瓦三相式两相 | 6、切刀成型模具 | 11、顶心键             | 16、倒柱模具下字模(或下料调节平台) |
| 2、机器转动方向轮                      | 7、机芯     | 12、剪刀口             | 17、送料对滚             |
| 3、电源开关                         | 8、送料限位   | 13、冲字轴承和偏心         | 18、退料三角调整时间         |
| 4、偏心轮                          | 9、退扣方键   | 14、冲字和高头立杆球头(或冲刺针) | 19、退料拐杆             |
| 5、滚针轴承                         | 10、小铲    | 15、倒柱模具上字模(或上刺模)   | 20、送料长短调节螺丝杆        |

- |                        |                    |  |                                     |
|------------------------|--------------------|--|-------------------------------------|
| 1 Double groove pulley | 6. Cutter mold     | 11. Top core key   | 15. he embossing mold device upper  |
| 2. Large wheel pulley  | 7. core plate      | 12. Scissors mouth   | 16. The embossing mold device lower |
| 3 Power switch         | 8. Feeding limit   | 13. Punching bearing and eccentric sleeve for embossing device | 17. Feeding to roll                 |
| 4. Eccentric           | 9. exit square key | 14. embossing punch pin  | 18. Return triangle                 |
| 5. Needle bearing      | 10. Small shovel   |  | 19 Withdrawal crutch                |
|                        |                    |  | 20. Feeding length adjustment screw |
|                        |                    |  | 21. Single clutch bearing           |